

Marine & Personal Watercraft

Extended Protection



Cruise with peace of mind.

Nationwide Protection

FCCP covers breakdowns occurring anywhere in Canada and the continental United States.

Transferable Coverage

In the event you choose to sell your watercraft, the coverage is fully transferable to the next owner for the remainder of the contract/policy term.

Reducing Deductible

Your deductible will be reduced by fifty dollars (\$50) when repairs are performed at the original selling dealer.



Cruise with peace of mind.

Cruise with a First Canadian Protection Plan.

Are you worried about unexpected breakdowns and unforeseen costly repairs? Today’s watercraft are equipped with many specialized parts and hi-tech components, and with the cost of repairs increasing each year, your new marine adventure could be more of a financial burden than originally planned. **FCPP can ease those worries.**

- Choose a protection plan to guard against unplanned expenses.
- Repair costs are paid directly to the repair facility, saving you from out-of-pocket expenses.

You're ready to hit the water, so why do you need this protection?

It's better to have protection and NOT NEED it, than to NEED it and NOT HAVE ANY.



Select the right plan for You.

Begin with our comprehensive standard plan

	Inboard	Outboard	Personal Watercraft
Engine	●	●	●
Lower Unit		●	●
Transmission		●	●
Fuel Delivery	●	●	●
Cooling System	●	●	●
Lubricating System	●	●	●
Steering	●	●	●
Electrical	●	●	●
Controls	●	●	●
Jet Drive	●		●
V-Drive			●
Power Trim and Tilt		●	●
Intermediate Housing			●
Trailer	●	●	●

Choose your Options:

Any option or combination of options can be added to the Outboard or Inboard plans.

	Sportsman	Onboard	Ski / Wake	Deluxe Cruiser
Electrical Accessories		●		●
Power Transom				●
Electric Trolling Motor				●
Outboard Trolling Motor or Electric				●
Canvas Top				●
Upholstery				●
Monitoring System				●
Depth Finder/Fish Finder		●		●
Air Conditioning/Heating			●	
Furnace			●	
Fresh Water Assembly			●	
Range and Oven Assembly			●	
Refrigerator Assembly			●	
Accessories			●	
Dual Station			●	
Deluxe Electronics	●	●		
Integrated On-board Control System		●		
Wake Plate System		●		

Schedule of Coverage

ENGINE

All Internal Lubricated Parts including:

Pistons; Piston Rings & Pins	●	●	●
Crankshaft & Main Bearings	●	●	●
Connecting Rods & Rod Bearings	●	●	●
Reeds & Reed Blocks	●	●	●
Oil Pump	●	●	●
Cam Shaft & Bearings	●	●	●
Timing Chain & Gears	●	●	●
Rocker Arms	●	●	●
Push Rods	●	●	●
Valve Lifters	●	●	●
Valve Cover(s)	●	●	●
Intake/Exhaust Manifolds	●	●	●
Harmonic Balancer	●	●	●
Oil Pan	●	●	●
Engine Mounts	●	●	●
Distributor Housing	●	●	●
Shafts & Bearings	●	●	●
All internal parts within the Turbocharger Housing, Turbo Waste Gate Actuator, Flywheel, Cylinder Head(s), Engine Block and Turbocharger Housing are covered only if damaged by the failure of an internally lubricated part. Seals and Gaskets associated with listed components.	●	●	●

LOWER UNIT

All Internal Lubricated Parts contained within the Lower Unit Case including:

Gear Case Head		●	●
Bearing and Oil Retainer		●	●
Driveshaft and Upper Bearing		●	●
Shift Rod and/or Cover Assembly		●	●
Pinion Bearing		●	●
Forward and/or Pinion Gears		●	●
Carrier Bearings		●	●
Shims		●	●
Thrust Washers		●	●
Propeller Shaft		●	●
Lower Unit Housing is covered only if damaged by the failure of a covered part. Seals and Gaskets associated with listed components.		●	●

TRANSMISSION

All internally lubricated parts contained within the Transmission Case. The Transmission Case is covered only if damaged by the failure of an internally lubricated part. Seals and Gaskets associated with listed components.

FUEL DELIVERY

Fuel Injectors	●	●	●
Fuel Distributors	●	●	●
Fuel Injection Pumps	●	●	●
Fuel Delivery Pump	●	●	●
Flame Arrester	●	●	●
Seals and Gaskets associated with listed covered components.	●	●	●

COOLING SYSTEM (Closed System only)

Circulating Water Pump	●	●	●
Coolant Circulating Pump	●	●	●
Heat Exchangers	●	●	●
Seals and Gaskets associated with listed components.	●	●	●

LUBRICATING SYSTEM

Oil Injection Check Valve	●	●	●
Injection Pump	●	●	●
Pump Drive Gear	●	●	●
Pump Drive Shaft	●	●	●
Low Oil Sensor	●	●	●
Oil Tank	●	●	●
Tank Cap	●	●	●
Pickup Tube	●	●	●
Warning Horn and/or Light	●	●	●
Oil Lines	●	●	●
Complete Metering System	●	●	●
Seals and Gaskets associated with listed components.	●	●	●

STEERING

Steering Control Helm Assembly	●	●	●
Steering Bracket and Bushing	●	●	●
Swivel Bracket and Bearing	●	●	●
Control Rack and Yoke Assembly	●	●	●
Power Steering Pump	●	●	●
Power Cylinder Assembly	●	●	●
Steering Wheel, Hub and Steering Cables	●	●	●
Seals and Gaskets associated with listed components.	●	●	●

ELECTRICAL

Alternator	●	●	●
Rectifier	●	●	●
Voltage Regulator	●	●	●
Power Trim and Tilt Motor	●	●	●
Starter Motor and Solenoids	●	●	●
Windshield Wiper Motor	●	●	●
Power Pack	●	●	●
Ignition Module	●	●	●
Sensors	●	●	●
ECU/Fuel Injection Modules	●	●	●
Wiring Harness	●	●	●
Limit and Control Switches	●	●	●
Trigger Coil and Stator	●	●	●


CONTROLS

Throttle Assembly	●	●	●
Remote Control Starter/Choke Primer Switch	●	●	●
Starter/Stop Button	●	●	●
Trim/Tilt Switch and Ignition Switch.	●	●	●

JET DRIVE

All internally lubricated parts within the Pump Housing. Pump Housing is covered only if damaged by the failure of an internally lubricated part. Pump Impeller and Wear Ring are not covered. Consequential damage from the Pump Impeller is not covered. Seals and Gaskets associated with listed components.

Schedule of Coverage




V-DRIVE

All internally lubricated parts contained within the V-Drive Case including:

Gears				●
Carrier Bearings				●
Shims				●
Thrust Bearings and Shaft				●
V-Drive Case is covered only if damaged by the failure of an internally lubricated part. Seals and Gaskets associated with listed components.				●

POWER TRIM & TILT

Spring		●	●
Sending Unit		●	●
Oil Pump		●	●
Pump Relief Valve		●	●
O-Ring		●	●
Trim Cylinder		●	●
Tilt Cylinder		●	●
Hydraulic Pump		●	●
Manual Release Valve		●	●
Reverse Lock Valve		●	●
Solenoids		●	●
Seals and Gaskets associated with listed covered components.		●	●



INTERMEDIATE HOUSING

Intermediate Shaft				●
Bearings				●
U-Joints				●
Centre Yoke				●
Drive Yoke				●
Gimble Bearings				●
Bellows (if defective)				●
Steering Yoke				●
Engine Coupler				●
Intermediate Housing is covered only if damaged by the failure of an internal part. Seals and Gaskets associated with listed components. Any breakdown caused by holes in, or leakage of, bellows or boots is not covered.				●

TRAILER

Master Cylinder	●	●	●
Hydraulic Brake Actuator	●	●	●
Backing Plates	●	●	●
Trailer Frame Welds	●	●	●
Spring Hanger Brackets and U-Bolts	●	●	●
Roller Cradles (Excluding Rollers)	●	●	●
Manual Winch and Stand	●	●	●
Axles and Spindles	●	●	●
Seals and Gaskets associated with listed covered components.	●	●	●

EXPERIENCE BASED REFUND (EBR) / GUARANTEED PRICE REBATE (GPR)

(Available on qualifying plans)


If the plan you select includes EBR/GPR, you can apply for a refund as soon as the contract/policy has expired by time. Refunds are based on the amount you originally paid for the contract/policy, up to a maximum of \$1,500, less your deductible.

- Original contract/policy holder must still be registered owner.
 - No mechanical or any other benefit claims made during the entire term.
 - Refund must be requested and received in the allotted time frame.
- Some restrictions apply - see contract/policy for details



Optional Coverages:

Any option or combination of options can be added to the the Outboard or Inboard plans.




ELECTRICAL ACCESSORIES

Voltage and all Pressure Gauges; Fuel Gauge; Speedometer and Tilt/Trim Gauge; Electronic Speed Control System; Sea/Lake Water Temperature Gauge including Sensor and Control Cable; Ballast Pump; Bilge Pump; Live Well Pump; Aerifier; PH Meter; Battery Main Switch and Selector Switch; Isolator Switch; Remote Spot Light; and Tack Head.				
--	--	--	--	--

POWER TRANSOM

Motor; Motor Bracket; Slide; Jack Screws & Cylinder; Control Switches & Wiring Harness. Seals & Gaskets associated with listed components.				
--	--	--	--	--

ELECTRIC TROLLING MOTOR

<p>All parts contained within the Motor Housing; Wiring Harness; Foot/Hand Speed Control; Steering Cable and Gears; Bow Arm Bracket. Seals & Gaskets associated with listed components.</p>				
---	--	--	--	---

OUTBOARD TROLLING MOTOR (UP TO 9.9 HORSEPOWER) OR ELECTRIC


Seals and Gaskets in Connection with a Breakdown of the Outboard Trolling Motor.				
--	--	--	--	--

CANVAS TOP

All Mechanical Components of Canvas Top System.				
---	--	--	--	--

UPHOLSTERY

Carpet; and fabric and vinyl covered furniture.				
---	--	--	--	--




MONITORING SYSTEM

Fume Detector; CO2 Detector; Fuel Vapor; and High Bilge Level Sensors.				
---	--	--	--	--


DEPTH FINDER/FISH FINDER

Unit; Wire Harness & Transducer.		●		●
----------------------------------	--	---	--	---


AIR CONDITIONING/HEATING

Condenser; Evaporator; Control Panel; Thermostat; Compressor Drive Motor; Capacitors; Relays; Fan & Compressor. Seals & Gaskets associated with listed components.			
---	--	--	---

FURNACE

Igniters; Burner Assembly; Thermostat; Thermocouple; Blower Motor; Heat Exchanger; Squirrel Cage; Time Delay Relay; PC Board; Seals & Gaskets associated with listed components.			
--	--	--	---


FRESH WATER ASSEMBLY


Water Pump; Compressor; Water Tank; Accumulator; Lines & Fittings; Faucets. Seals & Gaskets associated with listed components.				
--	--	--	---	--

RANGE & OVEN ASSEMBLY


Burner Assembly; Thermostat; Thermocouple; Microwave Oven; Power Hood.			
---	--	--	--

REFRIGERATOR ASSEMBLY

Thermostat; Thermocouple; Three Way Cooling Unit; Burner Assembly and Igniter; Fans; PC Board; Elements; Serviceable Refrigerator Door Seal; Wire Harness; and Seals & Gaskets associated with listed components.			
---	--	--	---



ACCESSORIES

Anchor Winch; Electric Windless/Winch; Light Fixtures; Light Switches; Shore Power Main Switch & Circuit Breakers; Bow Pulpit Guide and Switches; Battery Charger & Converter/ Inverter; including Voltage Regulators.			
--	--	--	---

DUAL STATION

Steering and Controls (the Parts and Components listed in the Part and Component Groups listed under Steering and Controls are covered for a second station if applicable).			
---	--	--	--

DELUXE ELECTRONICS

Satellite System; Auto Pilot; VHF Radio; GPS; Radar; Chart Plotter; Compass; Depth Sounder; All Electronic & Manual Gauges; Duel Throttle Synchronizer; Halon Fire System; Stereo; TV; DVD; VCR; CD Player; Bow Thruster System (except Propeller), Elec- tric Furling System.				
--	--	--	--	--

INTEGRATED ON-BOARD CONTROL SYSTEM

Cam Recording System; Cruise Control; and Perfect Pass System.				
--	--	--	--	--

WAKE PLATE SYSTEM

Hydraulic and Electrical; and Pump Sensors.				
---	--	--	--	--



Additional Benefits Included in **All Levels of Coverage**

No Deductible will apply to the following benefits:



TOWING

In the event of a breakdown, we will reimburse you for receipted towing expenses up to \$100 per occurrence (including taxes). This reimbursement will be for charges in excess of any reimbursement from the manufacturer or any other towing service coverage you may have.



TRIP INTERRUPTION

If a breakdown occurs more than 160km from your home and you have to leave your watercraft at a repair facility overnight, we will reimburse you for receipted lodging and meal expenses up to \$100 per day up to a maximum of \$400 per repair visit (including taxes). In order to qualify for Trip Interruption, your watercraft must be equipped with a minimum of one berth.



LIFT/HAUL OUT

In the event of a breakdown, we will reimburse all your receipted expenses up to \$100 per occurrence (including taxes) if it is necessary to remove your watercraft to perform repairs. This benefit only applies when repairs are covered under your plan.



Mechanical Breakdown Contracts
Administrator / Obligor
First Canadian Repair Protection
320 Sioux Road
Sherwood Park, AB T8A 3X6



Mechanical Breakdown Policies
Administrator / Underwriter
Millennium Insurance Corporation
320 Sioux Road
Sherwood Park, AB T8A 3X6

Toll-Free PH: 1.800.381.2580
Local PH: 1.780.467.9575
Toll-Free FX: 1.800.304.4031
Local FX: 1.780.467.9812

*NOTICE: The contents provided in this brochure are only a summary of certain terms and conditions of the Policy/Contract. Please refer to the actual Policy/Contract for complete details of coverage and exclusions. Not all Policies/Contracts are available in all provinces, and specific provisions may vary based upon individual provincial requirements.