


On-Road Motorcycle

Extended Protection



Cruise with peace of mind.

Nationwide Protection

FCPP covers your motorcycle anywhere in Canada and the continental United States.

Transferable Coverage

In the event you choose to sell your motorcycle, you can apply to transfer the coverage to the next owner for the remainder of the Policy/Contract term.

Reducing Deductible

Your deductible will be reduced by fifty dollars (\$50) when repairs are performed at the original selling dealer.



Cruise with peace of mind.

Protect against expensive Breakdowns

The manufacturer's original warranty coverage only lasts for a LIMITED time

- No mileage limitations or restrictions
- No need to worry about unexpected repairs
- Repair costs are paid directly to the repair facility, saving you from out-of-pocket expenses

By adding an FCPP Plan, you can protect your motorcycle for up to 84 months

You're buying a great bike, so why do you need this protection?
Mishaps can happen from time to time.

It's better to have protection and NOT NEED it,
than to NEED it and NOT HAVE ANY.

Select the right plan for You.

Ultimate
Powertrain

1	Engine	●	●
2	Turbocharger / Supercharger	●	●
3	Transmission	●	●
4	Primary Drive Components	●	●
5	Secondary Drive Components	●	●
6	Drive Axle	●	●
7	Chain Case Components	●	●
8	Oil Injection Components	●	●
9	Cooling System	●	●
10	Seals & Gaskets	●	●
11	Steering		●
12	Brakes		●
13	Electrical		●
14	Fuel System		●
15	Front & Rear Suspension		●
16	Frame		●

OPTIONAL PACKAGES		
1	Trailer Package	
2	Touring Package	

Comprehensive Coverage

Check out some of the PARTS that are covered on New and Used Motorcycles through FCPP Extended Protection Plans

Ultimate
Powertrain

ENGINE

All Internal Lubricated Parts within the engine, including:

Pistons; Piston Rings; Pinion Gears	●	●
Connecting Rods/Bearings	●	●
Crankshaft and main Bearings	●	●
Camshaft & Bearings; Cam Followers	●	●
Timing Chain or Belt	●	●
Timing Gears, Chain Cover, Guides & Tensioners	●	●
Rocker Arms, Shafts, Bushings, & Pivots	●	●
Sprocket Shaft Bearing; Tappets & Guides	●	●
Cylinder Head Valves; Headgasket	●	●
Valves, Valve Guides, Lifters, Springs, Seals & Covers	●	●
Push Rods; Oil Pump & Housing	●	●
Oil Pan; Oil Filter Mount; Oil Pressure Switch, Oil Pump, Drive Gear, Drive Shaft, Idler Gear	●	●
Pressure Relief Valve, Oil Screen Cover	●	●
Crank Pin & Bearing	●	●
Intake & Exhaust Manifolds, Valves & Manifold Gaskets	●	●
Engine Mounts/Isolators, Flywheel/Flexplate & Ring Gear	●	●
Cylinder Head(s); Engine Block & Barrels	●	●
Crankcase	●	●

TURBOCHARGER/SUPERCHARGER

(Factory Installed) Turbocharger/Supercharger Housing and all internal lubricated parts including:

Turbo Vanes; Shaft; Bushings; Waste Gate	●	●
--	---	---

Ultimate
Powertrain

TRANSMISSION

Housing (when damaged from within) and all internal lubricated parts.

Bearings; Bushings; Countershaft; Coupling; Gears;	●	●
Inner Ramp; Mainshaft; Manual & Hydraulic Linkages	●	●
Thrust Washers; Internal Selector Mechanism	●	●
Transmission Oil Cooler (factory installed only)	●	●
Switches, Sensors, Servos, Actuators & Module	●	●
Oil Pan & Gasket; Oil Spout Gasket; Oil Tank Seal	●	●
Outer Ramp; Pins & Plugs; Quad Seal; Ramp Balls	●	●
Retaining Ring; Spacers	●	●

PRIMARY DRIVE COMPONENTS

Housing (when damaged from within) and all internal lubricated parts including:

Chain Tensioner, Chain Tensioner Anchor Plate	●	●
Chain Tensioner Pad; Chain Tensioner Plate	●	●
Front Sprocket; Sheaves, Gears, Bearings & Bushings	●	●
Primary Chain; Shaft Extension; Sliding Cam	●	●
Spacers; Sprocket Cover; Grommets	●	●

SECONDARY DRIVE COMPONENTS

Stationary and Moveable Sheaves	●	●
Secondary Shaft & Bearings; Bushings; Cam Assembly	●	●

Ultimate
Powertrain

DRIVE AXLE

Differential, Transaxle & Final Drive Housings (when damaged from within) & all internal lubricated parts	●	●
Drive Shafts & Yokes; Universal Joints	●	●
Constant Velocity Joints	●	●
Axle Hub Bearings; Bearing Spacer Sleeves	●	●
Axle Shafts; Differential Covers	●	●
Supports & Retainers; Lock Rings	●	●
Crown & Pinion Gears	●	●

CHAIN CASE COMPONENTS

Housing (when damaged from within) and all internally lubricated parts.

Shafts; Gears & Sprockets	●	●
Chain & Adjuster Mechanism	●	●

OIL INJECTION COMPONENTS


Oil Injection Drive Gear	●	●
Oil Tank; Oil Level Sensor	●	●

COOLING SYSTEM

Engine Cooling Fan Motor	●	●
Temperature Gauge	●	●
Water Pump & Housing	●	●
Sending Unit	●	●
Radiator	●	●
Cooling Fan Sensor/Switch	●	●
Thermostat & Housing	●	●
Fan Relays	●	●

Comprehensive Coverage

Check out some of the PARTS that are covered on New and Used Motorcycles through FCPP Extended Protection Plans



SEALS AND GASKETS


Seals & Gaskets of any listed covered component. NOTE: Seepage is excluded	●	●
---	---	---

STEERING

Steering Stem & Bearings; Bearing Adjuster		●
Damper Tubes; O-Rings; Oil Seals		●
Roller Bearing & Cup; Steering Stem Shaft		●
Axle; Handle Bar; Tie-Rod Ends		●
Steering Links & Ends; Spindle Bushings		●


BRAKES

Master Cylinder; Master Cylinder Boot		●
Master Cylinder Cover; Master Cylinder Fittings		●
Master Cylinder Gaskets; Master Cylinder Reservoir		●
Master Cylinder Rod		●
Metal Hydraulic Brake Lines & Fittings		●
O-Rings, Pins, Spacers & Springs		●
Backing Plate; Brakes; Brake Rotors		●
Bleeders; Brake Rod Return Spring		●
Hinges & Lever(s); Calipers		●



ELECTRICAL

Alternator/Generator; Stator		●
Rectifier; Voltage Regulator		●
Starter Motor; Starter Solenoid; Starter Drive		●
Starter Armature; Starter Bearings & Brushes		●
Starter Bushings; Starter Field Windings; Starter Idler Gear		●
Starter Motor Case; Starter Pinion Gear; Starter Relay		●
Wiring Harness; Ignition Coil		●
Ignition Switch; Ignition Switch Lock Cylinder		●
Electronic Ignition Module/CDI		●
Electronic Fuel Injection Control Module/Sensor		●
Distributor; Stop Lamp Switch		●
Head Lamp Switch; Turn Signal Switch; Start/Stop Switch;		●
Brake Light Relay; Brake Light Relay Switch; Coil Cover		●
Cruise Control Module; Servo & Switches		●
Dimmer Switch; Horn & Horn Contact Switch		●
Neutral Indicator Switch; Neutral Safety Switch		●
Parking Lamps Relay; Parking Lamps Switch		●
Passing Lamp Switch; Speaker Control Switch		●
Turn Signal Cancellor		●



FUEL SYSTEM

Fuel Pump; Fuel Injection Pump		●
Fuel Tank; Fuel Tank Sending Unit		●
Metal Fuel Lines & Fittings; Petcock		●
Accelerator Pump; Carburetor Vacuum Switch		●
Carburetor Gasket; Carburetor Linkage		●
Carburetor Rods & Spring; Carburetor Starter Valve		●
Control Cables; Fuel Injection Components		●
Pressure Regulator; Fuel Door Lock Cylinder; O-Rings		●

FRONT & REAR SUSPENSION

all internally lubricated parts of:

Front Fork Tubes; Fork Stem & Nuts		●
Fork Stem Bracket; Fork Stem Dust Shield		●
Plugs; Springs; Snap Rings; Spacers & Stops		●
Slider Assemblies; Slider Tube & Springs		●
Bushings & Nut Bearings & Bushings		●
Swing Arm Shaft; Control Arms; Ball Joints		●
Wheel Bearings; O-Rings; Roller Bearings		●

FRAME

Axle(s); Brackets; Hubs; Spring Hangers		●
Welds; Couplers; Suspension Springs; Fenders		●

OPTIONAL PACKAGES

TRAILER PACKAGE

Master Cylinder
Hydraulic Brake Actuator
Backing Plates
Trailer Frame Welds
Spring Hanger Brackets and U-Bolts
Axles, Spindles, and Wheel Bearings
Manual Winch

TOURING PACKAGE

Electronic Transmitting Devices
Digital Dash Components
Amperage Gauge
Fuel Gauge
Oil Pressure Gauges
Speedometer
Tachometer
Temperature Gauge
Sound System

A WIN-WIN
situation for you



Some Plans offer you EBR/GPR Coverage:

If you experience a breakdown, the repairs are covered or if you never make a claim, you can get up to \$1,500 cash back.

EBR (Experience Based Refund)

(Coverage included with select Mechanical Breakdown Insurance Policies)

If the Plan selected on your Mechanical Breakdown Insurance Policy includes EBR, you can apply for a refund as soon as the Policy has expired by time. Refunds are based on the amount you originally paid for the Policy, up to a maximum claim amount of \$1,500.

- Original Contract holder must still be registered owner.
- No mechanical or any other benefit claims were made during the entire term.
- EBR claim must be requested and received in the allotted time frame.

See EBR terms and conditions on Policy for complete details

OPTIONAL GPR Coverage

(Available on qualifying Mechanical Breakdown Contracts) **Guaranteed Price Rebate (GPR):**

If you selected and paid the GPR Fee on an eligible plan, you can apply for a rebate claim as soon as the Contract term has expired by time. Rebates are based on the amount you originally paid for the Contract, up to a maximum amount of \$1,500. Criteria for the GPR claim include:

- Original Contract holder must still be registered owner.
- No mechanical or any other benefit claims were made during the entire term.
- GPR claim must be requested and received in the allotted time frame.

See GPR terms and conditions on Contract for complete details



Additional Benefits Included in **All Levels of Coverage**

Starting from the purchase date of the Policy/Contract, and included while your motorcycle is still covered by the manufacturer warranty.



RENTAL

In the event of a covered breakdown, we will pay or reimburse you for receipted expenses to rent a replacement vehicle/motorcycle or reimburse you for actual taxi or public transportation expenses.*
Up to \$50 per day, Maximum of \$250 per repair.



TRIP INTERRUPTION

In the event that a covered breakdown occurs more than one hundred and sixty (160) kilometres from your home and results in a repair facility keeping your vehicle overnight, we will pay for receipted motel and restaurant expenses.*
Up to \$100 per day, Maximum of \$300 per repair.



EMERGENCY ROAD SERVICE

In the event your motorcycle becomes disabled and requires on-site assistance, we will provide you with 24-hour Emergency Road Service **(1.800.516.3385)**, which includes Mechanical First Aid, Tire, Battery, Delivery, Towing and Locksmith Service.*
Up to \$240 per claim.

*Some restrictions apply - see Policy/Contract for complete details.



Mechanical Breakdown Contracts

Administrator / Obligor

First Canadian Repair Protection
320 Sioux Road
Sherwood Park, AB T8A 3X6



Mechanical Breakdown Policies

Administrator / Underwriter

Millennium Insurance Corporation
320 Sioux Road
Sherwood Park, AB T8A 3X6

Toll-Free PH: 1.800.381.2580
Local PH: 1.780.467.9575
Toll-Free FX: 1.800.304.4031
Local FX: 1.780.467.9812

*NOTICE: The contents provided in this brochure are only a summary of certain terms and conditions of the Policy/Contract. Please refer to the actual Policy/Contract for complete details of coverage and exclusions. Not all Policies/Contracts are available in all provinces, and specific provisions may vary based upon individual provincial requirements.